

RED CABOOSE

WHEELING & LAKE ERIE HO X-29 Box Car

To make your W&LE kit closer to prototype you should:

1. Instruction #5, do cut the end door stop off, 8a.
2. Instruction #5, do add the two door stops # X102.
3. It appears that these cars did receive AB brakes prior to becoming NKP cars. So install the AB brake system.

But

Some of these cars may have retained the brake staff, K-3, the brake wheel, K-4, lower brake staff support, K-7 and the brake platform, K-2 and brake platform brackets # 13 instead of receiving the power hand brake mechanism etc. on the end.

So, if you choose to apply AB brakes with the K-brake brake staff and platform etc. on the end refer to the addendum sheet as needed.

4. Use the 3 panel doors on this car, #9a

The closest match for paint is Scalecoat #2, Oxide Red. Test before applying.

August 1997

RED CABOOSE

P.O. Box 250 • Mead, CO 80542

May 1998